



Breathe Cool – Stay Safe

DRÄGER X-PLORE® 1300
DRÄGER X-PLORE® 1700
NIOSH VERSIONS



The Dräger X-plore® 1300 Series

Proven comfort, sophisticated ideas, safe respiratory protection

The new Dräger X-plore® 1300 — developed on the basis of several years of intensive market experience by analyzing customer requirements and market demands — sets new standards on comfort levels for particulate respirators. The result: an extremely comfortable, pre-formed dust mask for protection against particles. Its efficient CoolSAFE™ filter material and ergonomic design make the Dräger X-plore® 1300 a disposable dust mask with superior comfort, safety and user acceptance.

DRÄGER X-PLORE® 1350 N95



D-5180-2010

Dräger X-plore® 1350 N95
XS, S/M, M/L



D-5184-2010

Dräger X-plore® 1350
N95 V S/M, M/L



D-5178-2010

Dräger X-plore® 1350
N95 V Odor S/M, M/L

DRÄGER X-PLORE 1360 R95



D-5188-2010

Dräger X-plore® 1360 R95
S/M, M/L



D-5190-2010

Dräger X-plore® 1360
R95 V S/M, M/L



D-1337-2010

Dräger X-plore® 1360
R95 Odor S/M



CoolSAFE™ filter material
Performance that makes a difference: CoolSAFE™ filter material produced from high-performance filter media combines low breathing resistance and high filter performance in one mask.

Flexible nose clip
Ensures a great fit in the most critical area.

Nose seal
Secure sealing in the most critical area: all face pieces are equipped with special nose seal. It is sweat-absorbing, comfortable and most importantly ensures an effective seal around the nose.

Formed mask body:
Proven, ergonomic, stable
The special design and shape of the mask body offers a comfortable and secure fit to a wide variety of faces. The interior volume ensures wearing comfort along with easy communication. Additionally, the mask body is specially reinforced and keeps its form, springing back into its original shape, even when crushed. A stable, robust, and comfortable fit over long periods of time.



VarioFLEX™ head harness with EasyStop
Easy to don/doff and adjust with a pressure-free fit: This continuous loop head harness is constructed from a robust, tear-proof textile strap. In contrast to other face pieces, no clips are required – preventing uncomfortable pressure and allergic reactions. The head harness can be donned/doffed easily and quickly, and without hair entanglement. Thanks to EasyStop, the head harness can easily be adjusted to fit various head sizes while sitting comfortably and safely.

CoolMAX™ exhalation valve (optional)
Breathe easy and comfortably with extremely low breathing resistance. The exhalation valve releases humid and warm air, preventing heat build-up inside the mask, allowing you to stay cool while working hard.

Hypoallergenic inner layer
Comfortable to wear: the hypoallergenic inner layer is easy on your skin and gives the user added comfort even when used for longer periods of time.

NEW IN THE FAMILY

Extra small size:
The X-plore 1350 N95 is also available in an extra small size for smaller faces.



D-5180-2010

NEW IN THE FAMILY

Additional odor version
Odor version now also available with protection class R95 in S/M size in addition to X-plore 1350 N95 in S/M or M/L size.



D-1337-2010

Color coding
The nose clip and valve of the X-plore 1300 are differently colored to quickly identify the protection class:
- N95 dark blue
- R95 light blue



D-5180-2010 / D-5184-2010



The Dräger X-plore® 1700 Series

Breathe easier and work safely

The Dräger X-plore® 1700 series has been developed in cooperation with users for the specific requirements in the areas of industry, specialized trades and services. It sets new standards for comfort and use, performance and protection, along with modern design.

With its CoolSAFE™ filter material, it offers effective protection against particles. A hydrophobic material layer prevents moisture from exhaled air from seeping into the mask, keeping the filter media dry. This means breathing resistance remains consistently low, allowing the user to work easily and without tiring during extended use.

DRÄGER X-PLORE 1750 N95



ST-9493-2007

Dräger X-plore® 1750 N95



ST-9662-2007

Dräger X-plore® 1750
N95 V



ST-14189-2007

Dräger X-plore® 1750
N95 V Odor

DRÄGER X-PLORE 1760 R95



ST-14188-2007

Dräger X-plore® 1760 R95 V



D-17959-2010



D-17219-2010



D-17804-2010

CoolSAFE™ filter material

Performance that makes a difference: CoolSAFE™ filter material produced from high-performance filter media ideally combines low breathing resistance and high filter performance in one mask.

Flexible nose clip

Ensures a great fit, in the most critical area.

Soft inner layer

Comfortable to wear: the inner material layer is not only soft and hypoallergenic, but also repels moisture thanks to its hydrophobic properties, keeping breathing resistance consistently low, when used for longer periods of time.

VarioFLEX™ head harness

This continuous loop head harness is constructed from a stable, elastic, textile strap which is easy to don and doff while ensuring a comfortable fit. The soft, tearproof elastic strap fits various sizes of heads and prevents hair entanglement.

Hygienic individual packaging

Each facepiece is individually packed and sealed in a plastic bag, ensuring it stays clean and hygienic.

CoolMAX™ exhalation valve (optional)

Breathe easy and comfortably: thanks to an extremely low breathing resistance. Additionally, the specially engineered CoolMAX™ exhalation valve releases humid and warm exhaled air, preventing heat build-up inside the mask, allowing you to stay cool.



ST-8662-2007

Folded form

All Dräger X-plore 1700s are flat-folded, saving space and making them easier to transport.

Additional odor version

The odor version is equipped with an activated carbon layer which filters out unpleasant nuisance odors.



ST-14196-2007

Nose pad

Safe sealing in the most critical area: all particulate respirators are equipped with a high-quality, foam nose pad. It is comfortable and ensures a secure seal around the nose.



ST-9494-2007

Proven respiratory protection with intelligent solutions



COOLSAFE™ FILTER MATERIAL

The specially engineered CoolSAFE™ filter material combines various high-performance filter media to achieve an excellent filter performance. Coarse and fine particles are effectively stopped in the various filter layers. At the same time, breathing resistance remains very low, allowing the user to work comfortably for longer periods.



COOLMAX™ EXHALATION VALVE

Small details, big effect: the CoolMAX™ exhalation valve was engineered to optimally guide the exhaled air out of the face piece. The extremely low breathing resistance keeps breathing easy. Effective exhalation of humid and warm air successfully prevents heat build-up under the face piece. The result: the user enjoys the highest levels of breathing comfort.



EFFECTIVE SEAL

Alongside the material's filter performance, a secure seal without leakage is decisive in how effective the masks' protection really is. Depending on the protection class, the X-plore 1300 face pieces are equipped with a soft foam nose pad (N95) or a large comfort sealing strip (R95). The X-plore 1700 series comes standard with a soft foam nose pad. The combination of an inner seal and nose clip holds the mask effectively in place in the critical area around the nose.



ODOR VERSION

Odor versions are equipped with an activated carbon layer which filters out unpleasant nuisance organic odors. N95 protection classes are available for the X-plore 1300 and 1700 series, R95 protection class is available for the X-plore 1300 series.



NEW IN THE FAMILY - EXTRA SMALL SIZE AND ADDITIONAL ODOR VERSION

The X-plore 1350 N95 offers an extra small size, especially for those with a small face. The R95 odor version is available in a small/medium size and fits for tasks where nuisance odors are present.



ORDER INFORMATION

Dräger X-plore® 1300	Size	Rating	Pieces per Box	Order No.
Dräger X-plore 1350	XS	N95	20	39 51 351
Dräger X-plore 1350	S/M	N95	20	39 51 352
Dräger X-plore 1350	M/L	N95	20	39 51 353
Dräger X-plore 1350 V	S/M	N95	10	39 51 355
Dräger X-plore 1350 V	M/L	N95	10	39 51 356
Dräger X-plore 1350 V Odor	S/M	N95	10	39 51 358
Dräger X-plore 1350 V Odor	M/L	N95	10	39 51 359
Dräger X-plore 1360	S/M	R95	20	39 51 362
Dräger X-plore 1360	M/L	R95	20	39 51 363
Dräger X-plore 1360 V	S/M	R95	10	39 51 365
Dräger X-plore 1360 V	M/L	R95	10	39 51 366
Dräger X-plore 1360 Odor	S/M	R95	20	39 51 368
Dräger X-plore® 1700				
Dräger X-plore 1750		N95	20	39 51 320
Dräger X-plore 1750 V		N95	15	39 51 321
Dräger X-plore 1750 V Odor		N95	15	39 51 322
Dräger X-plore 1760 V		R95	15	39 51 326

TECHNICAL DATA

Filter material	CoolSAFE™ for protection against particles; N-rated for particulate aerosols free of oil, maximum use of one work-shift R-rated for particulate aerosols containing oil, maximum use of one work-shift
Odor versions	With additional activated carbon layer against nuisance organic odors below the limit value
Approvals	All versions are approved according to NIOSH 42 CFR Part 84.

HEADQUARTERS

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES

CANADA

Draeger Safety Canada Ltd.
7555 Danbro Crescent
Mississauga, Ontario L5N
6P9
Tel +1 905 821 8988
Fax +1 905 821 2565

USA

Draeger Safety, Inc.
101 Technology Drive
Pittsburgh, PA 15275
Tel +1 412 787 8383
Fax +1 412 787 2207

MEXICO

Draeger Safety, S.A. de C.V.
Carretera Oro - SLP Km 21,
Bodegas 1 y 2
Poligono Empresarial
Santa Rosa, Jauregui
Queretaro, Mexico
Tel +52 442 246-1113
Fax +52 442 246-1114

P. R. CHINA

Beijing Fortune Draeger
Safety Equipment Co., Ltd.
Yu An Lu A 22, B Area
Beijing Tianzhu Airport
Industrial Zone
Houshayu Shunyi District
Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

INDONESIA

Pt. Draegerindo Jaya
Jl. Kemang Selatan VIII No. 51
Kelurahan Bangka
Jakarta Selatan 12730,
Indonesia
Tel +62 21 7 18 14 32
Fax +62 21 7 18 14 34

JAPAN

Draeger Safety Japan Ltd.
3-8-1 Toyo
2-chome, Koto-Ku
Tokyo 135-0047,
Japan
Tel +81 3 44 61 51 11
Fax +81 3 44 61 51 00

KOREA

Draeger Safety Asia
Korea Representative Office
Daejong Bld. #1106
Bang-l-dong, Songpa gu
Seoul, Korea
Tel +82 2 64 15-8222
Fax +82 2 64 15-8223

MALAYSIA

Draeger Safety Asia Pte. Ltd.
(Malaysia Branch)
14 Jalan PJS 11/18
Taman Bandar Sunway
46150 Petaling Jaya
Selangor Darul Ehsan,
Malaysia
Tel +60 3 735 64 60
Fax +60 3 735 41 71

SINGAPORE

Draeger Safety Asia Pte Ltd
67 Ayer Rajah Crescent #06-03
Singapore 139950
Tel +65 68 72 92 88
Fax +65 65 12 19 08

TAIWAN

Draeger Safety Taiwan Co. Ltd.
12/F, Kuohwa Building,
Chungcheng Rd
Chungho City
Taipei county 235
Tel +886 02 22 23-6388
Fax +886 02 22 23-2258

JOSEPH LESLIE

DRÄGER MFG. PVT. LTD.
Leslico House 4th Floor
Prof. V.S. Agashe Road
Dadar (W), Mumbai 400 028